





# OPEN / CLOSED PANEL ILLUSTRATION

Damaged Front Column




Determine which struts fall below the top horizontal of repair kit. Remove all those struts except for the factory diagonal that intersects with the top horizontal strut on the kit. Measure the intersecting point of diagonal strut and cut at that point. (Follow installation manual for complete Elite installation instructions)

Incorrectly Installed Elite Vertical Kit With Open Panel




Industry standards prohibit open panels.

Correctly Installed Elite Vertical Kit With Closed Panel



Cut the factory diagonal strut to length for reconnection above repair kit. Fasten to repair kit using (1) Reconnection Angle or Channel and (2) 3/8" diameter Tek screws. Connect strut to reconnection component with supplied fasteners. (All required components are included)

Existing factory frame and struts is shown in red. Mac Rak repair kit and reconnection hardware are shown in green and blue.



Field locate to center of strut intersection.